



Email : sales@testinglabinstruments.com

Product Name :
Cutter for Block Grease

Product Code :
TEST5080RFQLAB-0009



Description :

Cutter for Block Grease

Technical Specification :

For trimming the grease block for penetration tests.

It consists of a base on which two pillars are mounted vertically. A cutting blade fixed to two guides slides freely on the two pillars. An 'L' bracket is fixed on one side of the base at right angles to the blade and it acts as a guiding edge for the block. A handle is welded in between the blade guides. A maximum block of 150 mm x 100 mm cross section can be accommodated in this cutter.

We are a leading manufacturer of Cutter for Block Grease testing equipment for a range of industries, including materials science testing lab. We offer full range of Cutter for Block Grease testing equipment, including Cutter for Block Grease testing kit, Cutter for Block Grease testing machine, Cutter for Block Grease testing tools, Cutter for Block Grease test equipment, Cutter for Block Grease test machines, Cutter for Block Grease for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Cutter for Block Grease testing equipment that helps customers build better, safer, and more sustainable infrastructure.

Testing lab instruments India

