



Email : sales@testinglabinstruments.com

**Product Name :**  
Slotted Tube Sampler for Bulk Cement

**Product Code :**  
TEST5052RFQLAB-0002



**Description :**

Slotted Tube Sampler for Bulk Cement for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

These samplers are used for sampling of cement from wagons and from ship's hold. The sampler consists of two telescopic brass tubes with slots along their lengths. The slots can be opened for collecting the sample and then closed by rotating the inner tube. The tube has a conical end for easy penetration. These samplers are between 1.5 to 1.8 m long with about 35 mm O.D for sampling from ship's hold and can be used up to 2m depth. These are about 60 cm in length when required to be used for sampling from wagons.

We are a leading manufacturers of Slotted Tube Sampler for Bulk Cement testing equipment for a range of industries, including materials science testing lab. We offer full range of Slotted Tube Sampler for Bulk Cement testing equipment, including Slotted Tube Sampler for Bulk Cement testing kit, Slotted Tube Sampler for Bulk Cement testing machine, Slotted Tube Sampler for Bulk Cement testing tools, Slotted Tube Sampler for Bulk Cement test equipment, Slotted Tube Sampler for Bulk Cement test machines, Slotted Tube Sampler for Bulk Cement for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Slotted Tube Sampler for Bulk Cement testing equipment that helps customers build better, safer, and more sustainable infrastructure.

---

# Testing lab instruments India

