

Product Name :
Tile Abrasion Testing Machine

Product Code :
TEST5067RFQLAB-0017



Description :

Tile Abrasion Testing Machine

Technical Specification :

Used for determining the resistance of flooring tiles to wear or abrasion.

It consists of the following :-

A grinding disc furnished with a replaceable grinding path and rotating horizontally about its vertical axis.

A circular tray enclosing the grinding disc.

Holding device for test specimen.

Reduction gear coupled to a motor for operation on 220 v, 50 Hz, single phase supply electronic.

Revolution counter. (Preset cumulative).

A 7.5 kg weight to apply 30 kg load on specimen through lever.

We are a leading manufacturers of Tile Abrasion Testing Machine testing equipment for a range of industries, including materials science testing lab. We offer full range of Tile Abrasion Testing Machine testing equipment, including Tile Abrasion Testing Machine testing kit, Tile Abrasion Testing Machine testing machine, Tile Abrasion Testing Machine testing tools, Tile Abrasion Testing Machine test equipment, Tile Abrasion Testing Machine test machines, Tile Abrasion Testing Machine for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Tile Abrasion Testing Machine testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India