

Product Name :
Retractable Hydraulic Jacks

Product Code :
TEST5068RFQLAB-0003



Description :

Retractable Hydraulic Jacks

Technical Specification :

These jacks are specially designed for use in inverted position i.e. for loading from top to bottom. A base plate with holes is provided in the jack to fix it with a loading frame of appropriate capacity. A retracting spring is incorporated in the jack and ram assembly which pulls the ram back into the jack cylinder after the release of the load. The pumping units are similar to the ones supplied with remote controlled hydraulic jacks listed.

Cap Sensitivity

50 KN 0.5 KN
100 KN 1.0 KN
150 KN 1.0 KN
200 KN 2.0 KN
250 KN 2.0 KN
500 KN 5.0 KN
750 KN 5.0 KN
1000 KN 5.0 KN
2000 KN 10.0 KN

We are a leading manufacturers of Retractable Hydraulic Jacks testing equipment for a range of industries, including materials science testing lab. We offer full range of Retractable Hydraulic Jacks testing equipment, including Retractable Hydraulic Jacks testing kit, Retractable Hydraulic Jacks testing machine, Retractable

Hydraulic Jacks testing tools, Retractable Hydraulic Jacks test equipment, Retractable Hydraulic Jacks test machines, Retractable Hydraulic Jacks for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Retractable Hydraulic Jacks testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India