



Email : sales@testinglabinstruments.com

Product Name :
Central Hole Jacks

Product Code :
TEST5068RFQLAB-0005



Description :

Central Hole Jacks

Technical Specification :

These jacks are specially designed for pull out tests on foundation bolts, rock bolts or the like and are extensively used by Structural Engineers and Research Institutions. These jacks have a hole in the centre and are designed for dual operation. The hand pump is specially designed with two control lines i.e. one for extraction and the other for retraction. Separate control valves are provided. A calibrated load gauge is provided with each jack to read the load directly. Lifting handles are provided on jacks and pumps for ease of transportation.

Cap Sensitivity
100 KN 1.0 KN
250 KN 2.0 KN
500 KN 5.0 KN
1000 KN 5.0 KN

We are a leading manufacturers of Central Hole Jacks testing equipment for a range of industries, including materials science testing lab. We offer full range of Central Hole Jacks testing equipment, including Central Hole Jacks testing kit, Central Hole Jacks testing machine, Central Hole Jacks testing tools, Central Hole Jacks test equipment, Central Hole Jacks test machines, Central Hole Jacks for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Central Hole Jacks testing equipment that helps customers build better, safer, and

more sustainable infrastructure.



Testing lab instruments India