



Email : sales@testinglabinstruments.com

Product Name :
Sand Equivalent Test Apparatus

Product Code :
TEST5007RFQLAB-0006



Description :

Sand Equivalent Test Apparatus

Technical Specification :

The apparatus is used to determine the relative proportion of fine dust or clay like material in soils or fine aggregates either in the laboratory or in the field. It is performed as. The apparatus consists of the following:-
Measuring cylinder of transparent acrylic, graduated up to 380mm, complete with a rubber stopper.

One irrigator tube of stainless steel.

Siphon Assembly (without glass bottle) consisting of a rubber stopper with a long, bent copper tube, an air intake tube and rubber tube to connect to the irrigator tube, complete with a pinch clip.

Weighted foot assembly for sand level.

We are a leading manufacturers of Sand Equivalent Test Apparatus testing equipment for a range of industries, including materials science testing lab. We offer full range of Sand Equivalent Test Apparatus testing equipment, including Sand Equivalent Test Apparatus testing kit, Sand Equivalent Test Apparatus testing machine, Sand Equivalent Test Apparatus testing tools, Sand Equivalent Test Apparatus test equipment, Sand Equivalent Test Apparatus test machines, Sand Equivalent Test Apparatus testing Instruments. We are suppliers of materials testing tools equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Sand Equivalent Test Apparatus testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India