



Email : sales@testinglabinstruments.com

**Product Name :**  
Hydraulic Ground Anchor Spanner

**Product Code :**  
TEST5028RFQLAB-0004



**Description :**

Hydraulic Ground Anchor Spanner

**Technical Specification :**

To speed up insertion and retraction of anchors, Hydraulic Ground Anchor Spanner, designed to be operated by the Power Pack of the unit itself, can be supplied at extra cost. This unit works through a high torque low r.p.m. hydraulic motor and is light enough to be conveniently operated by two persons.

**PIEZO CONE**

has developed a Piezo cone with data acquisition system for on site, acquiring the data for various parameters like:-

Point resistance

Skin friction

Total resistance offered to cone & rods

Depth of penetration

Pore pressure

This piezo cone can be used with any of our 100kN Static Cone Penetrometer, or 200kN Static Cone Penetrometer with the change of bracket.

There are different model of cones to suite various site conditions. Most commonly used is the subtraction cone where as compression cone is used for soft areas. Cone area is 10cm.

We are a leading manufacturers of Hydraulic Ground Anchor Spanner testing equipment for a range of industries, including materials science testing lab. We offer full range of Hydraulic Ground Anchor Spanner testing equipment, including Hydraulic Ground Anchor Spanner testing kit, Hydraulic Ground Anchor Spanner

---

testing machine, Hydraulic Ground Anchor Spanner testing tools, Hydraulic Ground Anchor Spanner test equipment, Hydraulic Ground Anchor Spanner test machines, Hydraulic Ground Anchor Spanner for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Hydraulic Ground Anchor Spanner testing equipment that helps customers build better, safer, and more sustainable infrastructure.



## Testing lab instruments India