

**Product Name :**  
Piston Sampler

**Product Code :**  
TEST5028RFQLAB-0007



**Description :**

Piston Sampler

**Technical Specification :**

It is a thin walled sampler carrying a piston attached to a piston rod, which extends through the hollow drill rods to the ground surface. A locking ball cone clamp provided in the sampler rear prevents the piston from sliding down after the sample has been collected.

It consists of :-

Sampling tube 50.8 mm inside dia x 600 mm long – 1 No

Piston with piston rod – 1 No.

Adapter for connecting rod – 1 No.

Sampler head with adapter for A-rod and ball cone clamp – 1 No

We are a leading manufacturers of Piston Sampler testing equipment for a range of industries, including materials science testing lab. We offer full range of Piston Sampler testing equipment, including Piston Sampler testing kit, Piston Sampler testing machine, Piston Sampler testing tools, Piston Sampler test equipment, Piston Sampler test machines, Piston Sampler for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Piston Sampler testing equipment that helps customers build better, safer, and more sustainable infrastructure.

---

# Testing lab instruments India

