

**Product Name :**  
Powered by 4.8H.P. Diesel Engine

**Product Code :**  
TEST5036RFQLAB-0001



**Description :**

Powered by 4.8H.P. Diesel Engine for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

The machine is light weight, versatile and easy to operate. It has a tubular frame mounted on two pneumatic tyres. A hook is provided in the front side of the frame to be towed behind a jeep and the tyres have been so placed that the total machine is balanced. One person can pull the machine without any strain. Main gear box which gives a manual feed of 600 mm can be rotated in any direction that is 0-360o for a convenient angle of drilling. It is powered by 4.8 H.P. diesel engine, suitable for taking cores up to the diameter of 150 mm and depth more than 4-5 meters with help of extension rods (extension rods and bits to be ordered separately)

Water swivel and a water pump is fixed on to the main machine. A clutch has been provided to engage or disengage water pump depending upon the type of drilling that is required wet or dry.

We are a leading manufacturers of Powered by 4.8H.P. Diesel Engine testing equipment for a range of industries, including materials science testing lab. We offer full range of Powered by 4.8H.P. Diesel Engine testing equipment, including Powered by 4.8H.P. Diesel Engine testing kit, Powered by 4.8H.P. Diesel Engine testing machine, Powered by 4.8H.P. Diesel Engine testing tools, Powered by 4.8H.P. Diesel Engine test equipment, Powered by 4.8H.P. Diesel Engine test machines, Powered by 4.8H.P. Diesel Engine for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Powered by 4.8H.P. Diesel Engine testing equipment that helps customers build better, safer, and more sustainable infrastructure.



# Testing lab instruments India