

**Product Name :**  
Rock Core Gauge Testing

**Product Code :**  
TEST5038RFQLAB-0001



**Description :**

Rock Core Gauge Testing for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

Precision gauge for the measurement of:

- Height
- Squareness
- Flatness
- Parallelism

'NX' Core Gauge is a must for every well-equipped rock mechanics laboratory. All critical parts of the gauge are heat treated and ground to very close tolerances.

Measurements are made with the help of a dial gauge affixed to a ground removable slide plate.

In operation the rock core is placed between the top and bottom reference plates.

The dial gauge and slide plate are then positioned and the measurements are made by sliding the plate over the top reference plate. A right angle gauge is provided for squareness measurements. Standard bars are supplied for initial setting of the dial gauge.

We are a leading manufacturer of Rock Core Gauge testing equipment for a range of industries, including materials science testing lab. We offer full range of Rock Core Gauge testing equipment, including Rock Core Gauge testing kit, Rock Core Gauge testing machine, Rock Core Gauge testing tools, Rock Core Gauge test equipment, Rock Core Gauge test machines, Rock Core Gauge for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Rock Core Gauge testing equipment that helps customers build better, safer, and more

---

sustainable infrastructure.



## Testing lab instruments India