

Product Name :
Binder Ignition Tester Machine

Product Code :
TEST5119RFQLAB-0001



Description :

Binder Ignition Tester Machine for Testing Lab Equipment Tender Suppliers India

Technical Specification :

Asphalt binder tester is used to measure the weight loss of a bituminous mixture during combustion and automatically calculates its binder content at the end of the test. This binder testing equipment is designed and made as per the ASTM D6307, AASHTO TP53-95, BSDD250 standards of American National Center for Asphalt Technology (NCAT).

Max. sample weight: 4000g

Commendable sample weight: 1000-2000g

Balance accuracy: 0.1g

Balance range: 10kg

Combustion chamber dimension: 350x440x330mm

Max. working temperature of combustion chamber: 800?

Standard working temperature: 538?

Testing time: 1200g sample for 30min

Power supply: 380V/220V

We are a leading manufacturers of Binder Ignition testing equipment for a range of industries, including materials science testing lab. We offer full range of Binder Ignition testing equipment, including Binder Ignition testing kit, Binder Ignition testing machine, Binder Ignition testing tools, Binder Ignition test equipment, Binder Ignition test machines, Binder Ignition for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Binder Ignition testing

equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India