

**Product Name :**  
High Pressure Triaxial Cells

**Product Code :**  
TEST5040RFQLAB-0001



**Description :**

High Pressure Triaxial Cells for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

The unit consists of metallic high pressure chamber. A hardened, ground and lapped frictionless plunger passes through the removable head. The cylinder is fixed to a removable base plate having four drilled take off positions for lateral pressure, pore pressure, back pressure and top drainage. The specimen pedestal and loading pads are also hardened. Spherical seating is provided at the top of the specimen loading pad for self alignment.

Triaxial Cell has arrangement for taking out electrical leads of strain gauges pasted on the specimen. Provision is made to take out eight leads.

**Pressure Range**

- 7 Mpa
- 15 Mpa
- 35 Mpa
- 50 Mpa
- 70 Mpa

We are a leading manufacturers of High Pressure Triaxial Cells testing equipment for a range of industries, including materials science testing lab. We offer full range of High Pressure Triaxial Cells testing equipment, including High Pressure Triaxial Cells testing kit, High Pressure Triaxial Cells testing machine, High Pressure Triaxial Cells testing tools, High Pressure Triaxial Cells test equipment, High Pressure Triaxial Cells test machines, High Pressure Triaxial Cells for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use High

---

Pressure Triaxial Cells testing equipment that helps customers build better, safer, and more sustainable infrastructure.



## Testing lab instruments India