

Product Name :
Core Drilling Equipment

Product Code :
TEST5041RFQLAB-0001



Description :

Core Drilling Equipment for Testing Lab Equipment Tender Suppliers India

Technical Specification :

Compact and mobile, 'Core-drill' machine drills through hard rock, concrete, bitumen, tiles, marbles etc. and takes out cores for the preparation of laboratory samples. Drive is through a powerful two speed motor. It can easily cut cores upto 100 mm dia. The total assembly move on a pillar to adjust the tip height of the bit. Pillar is fixed on to a base with two wheels for site shifting. For big cores the base has to be clamped to the ground with anchor bolts. Anchor bolts, drill bit for making 16 mm holes, drill chuck are provided as standard along with the machine. Geared motor moves on a slide and the slide can be rotated through 360°. Travel of the geared motor is approximately 500 mm and the cores of 400-450 mm can be easily taken out in single operation. H.P. of the Motor : 1100 Watts Operates on : 220 Volts A.C. supply. Note : Machine is supplied without bits and barrels

We are a leading manufacturers of Core Drilling Machine testing equipment for a range of industries, including materials science testing lab. We offer full range of Core Drilling Machine testing equipment, including Core Drilling Machine testing kit, Core Drilling Machine testing machine, Core Drilling Machine testing tools, Core Drilling Machine test equipment, Core Drilling Machine test machines, Core Drilling Machine for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Core Drilling Machine testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India