

Product Name :
Dead Weight Type

Product Code :
TEST5042RFQLAB-0001



Description :

Dead Weight Type for Testing Lab Equipment Tender Suppliers India

Technical Specification :

The Controllers are designed to maintain confining pressure at the set value with the help of dead weights irrespective of any deformation that takes place during testing of the specimen. A series of relays are provided for automatic actuation of the main pumping unit depending upon the volume change in the specimen. A small fractional horse-power geared motor eliminates any static friction, by rotating the measuring ram.

All the electrical controls are easily accessible and are mounted on the front panel.

The unit operates on 440 volts, 3 phase, 50 hz supply.

- 7 Mpa in steps of 0.1 Mpa
- 15 Mpa in steps of 0.2 Mpa
- 35 Mpa in steps of 0.5 Mpa
- 50 Mpa in steps of 0.5 Mpa
- 70 Mpa in steps of 0.5 Mpa

We are a leading manufacturers of Dead Weight Type testing equipment for a range of industries, including materials science testing lab. We offer full range of Dead Weight Type testing equipment, including Dead Weight Type testing kit, Dead Weight Type testing machine, Dead Weight Type testing tools, Dead Weight Type test equipment, Dead Weight Type test machines, Dead Weight Type for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Dead Weight Type testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India