

Product Name :
Road Marking Retroreflectometer

Product Code :
TEST5127RFQLAB-0003



Description :

Road Marking Retroreflectometer for Testing Lab Equipment Tender Suppliers India

Technical Specification :

Road marking retroreflectometer is an open-optical-path designed small size portable on-site measuring instrument, the weight is 3.5kg.

Main use is to measure the in-night brightness of road marking made of retroreflective material simulating under illumination from the headlights of vehicles driving on road, i.e, the in-night brightness observed by the driver in vehicle.

The measured parameter is the nighttime retroreflective brightness coefficient, namely RL value.

This instrument test result accurate and repeatable, simple to operate, can be used in laboratory or field.

Open-optical-path design.

Suitable for measuring under 3 conditions:
dry RL, Wet and continuous Rainfall .

Fast measurement (measuring retroreflective brightness coefficient in 2 seconds).

Automatic calculating the average of results of multiple measurements.

Calibration system in line with international standards, only calibrate white color.

Long standby and fast recharging.

5-inch daylight screen.

Data storage more than 100,000 pcs.

GPS accurate positioning.

USB data interface, test report is exported to computer as database.

Measurement data real-time voice broadcast.

The Bluetooth printer prints the test results on spot.
Touching keyboard to edit.
Display temperature and humidity real time.
Measurement items: retroreflective coefficient (mcd.m-2.lx-1)
Measurement range: 0~4000
Observation angle: 1.05°
Angle of incidence: 88.76°, Complementary angle is 1.24°
Light source color temperature: 2856±50K
Measuring aperture area: 200mm x 95mm
Error of repeatable measurement: 2%
Continuous working time of battery: ?30h
Data storage space: 8GB
Built-in battery capacity: 12V, 5.2Ah
Charger: DC 15V
Working temperature & humidity: -15??60?, ?98%, no frost
Size: 360mm x 135mm x 125mm

We are a leading manufacturers of Road Marking Retroreflectometer testing equipment for a range of industries, including materials science testing lab. We offer full range of Road Marking Retroreflectometer testing equipment, including Road Marking Retroreflectometer testing kit, Road Marking Retroreflectometer testing machine, Road Marking Retroreflectometer testing tools, Road Marking Retroreflectometer test equipment, Road Marking Retroreflectometer test machines, Road Marking Retroreflectometer for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Road Marking Retroreflectometer testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India