

**Product Name :**  
Bitumen Partilce Charge Tester

**Product Code :**  
TEST5176RFQLAB-0006



**Description :**

Bitumen Partilce Charge Tester

**Technical Specification :**

Bitumen Partilce Charge Tester

This equipment is used for the identification of anionic and cationic bituminous emulsions used in road construction.

For this purpose, it has two electrodes that are introduced into the emulsion, connected to a continuous power supply, in which after a time of passing a current through the emulsion, it can be observed which of them has been deposited a binder film.

Milliammeter scale up to 10mA on support base

Digital

Two stainless steel Electrodes

500mm capacity beaker

Glass road

Power Supply : AC 230v 50-60Hz

