

**Product Name :**  
Standard Tar Viscometer Non Digital

**Product Code :**  
TEST5176RFQLAB-0011



**Description :**

Standard Tar Viscometer Non Digital

**Technical Specification :**

Standard Tar viscometer (non digital)

Viscosity is the property of the fluid by which it resist flow due to internal friction. Used for determining viscosity of cut – back bitumen and road oil. Viscosity is measured by determining the time taken by 50 cc of the material to flow from a cup through a specified orifice.

The apparatus consists of a bath with 10mm or 4mm orifice cups and sleeve stir with ball lifting clip.

The bath is fitted with a immersion heater.

Temperature is controlled by energy regulator.

Electrical heating with energy regulator control.

Accessories:

Thermometer IP 8C/IP9C/10C

10mm and 4mm orifice cups with valves

Measuring cylinder 100ml

Digital stop watch.

---

# Testing lab instruments India

