

**Product Name :**  
Los Angeles Abrasion Equipment

**Product Code :**  
TEST5176RTLABT-0034



**Description :**

Los Angeles Abrasion Equipment

**Technical Specification :**

Los Angeles Abrasion Machine

Los Angeles Abrasion Testing Machine consists of a hollow cylinder mounted horizontally on a study frame on ball bearings. There is an opening which can be closed with a dust tight cover to facilitate charging and discharging the drum with the material under test.

Rolled steel drum : Internal diameter 711mm and 508mm length

Drum Speed between 31 and 33 revolutions per minute

Drum incorporate removal internal shelf.

Electric motor driven

Automatic counter that can be preset to the required number drum revolutions or total working time

Graphic display and membrane keyboard.

Voltage 220- 240v 50-60Hz 1 Phase

