

Product Name :
Bottle Type Jacks

Product Code :
TEST5068RFQLAB-0001



Description :

Bottle Type Jacks for Testing Lab Equipment Tender Suppliers India

Technical Specification :

These are fully self contained jacks with integral pumping units and oil reservoirs. A detachable hand lever is provided for operation of pump. A 10 cm dia calibrated load gauge is supplied with each jack. Lifting handle is also provided on the jack.

Cap Sensitivity

50 KN 0.5 KN

100 KN 1.0 KN

200 KN 1.0 KN

250 KN 2.0 KN

500 KN 2.0 KN

Remote Controlled Jacks

These Jacks have a separate pumping unit connected to the jack by one meter long detachable high pressure flexible hose pipe. The jack, pump & hose pipe can be separated for easy transportation and reassembled at site. Jacks upto 500 kN capacity are supplied with hand operated single plunger pumping units and those above 500 kN are supplied with double plunger pumping unit. A 100 mm dia pressure gauge is provided with jacks upto 500 kN capacity and 200 mm dia pressure gauge for those of higher capacities.

Cap Sensitivity

50 KN 0.5 KN

100 KN 1.0 KN
150 KN 1.0 KN
200 KN 2.0 KN
250 KN 2.0 KN
500 KN 5.0 KN
750 KN 5.0 KN
1000 KN 5.0 KN
1500 KN 5.0 KN
2000 KN 10.0 KN
3000 KN 10.0 KN
5000 KN 25.0 KN

We are a leading manufacturers of Bottle Type Jacks testing equipment for a range of industries, including materials science testing lab. We offer full range of Bottle Type Jacks testing equipment, including Bottle Type Jacks testing kit, Bottle Type Jacks testing machine, Bottle Type Jacks testing tools, Bottle Type Jacks test equipment, Bottle Type Jacks test machines, Bottle Type Jacks for Lab Testing Instruments. We are suppliers of materials testing tools and equipment for the construction industry. Our mission is to provide reliable, accurate, and easy-to-use Bottle Type Jacks testing equipment that helps customers build better, safer, and more sustainable infrastructure.



Testing lab instruments India