

**Product Name :**  
Cordless Jigsaw

**Product Code :**  
TEST5185RFQLAB-0002



**Description :**

Cordless Jigsaw for Testing Lab Equipment Tender Suppliers India

**Technical Specification :**

Cordless jigsaw

Higher blade speed than corded jig saws for clean controlled cuts.

Power to cut hard materials including hardwoods and metals.

4 position orbital cutting provides versatility for application specific cutting.

Tool free shoe bevel with positive stops allows for quick and accurate shoe adjustment with pin-detents at 0°, 15°, 30° and 45°.

Variable speed trigger between 0 and 3500 strokes per minute, providing precise control for clean cuts with less chipping.

On/off cut line blower keeps the cut line clear of debris, and allows user to turn off blower when using dust extraction.

Top handle cordless jigsaw

Voltage: 18V

No load stroke rate: 0-3500spm

Stroke length: 25mm

Bevel cut angle: 450

Max cutting depth:

Wood:100mm

Steel:10mm

Battery: 5Ah

---

Battery replacement: 1Pc  
Case: Yes  
Kit includes:  
1Pc : Jigsaw  
2Pcs: Battery  
1Pc: Case



**Testing lab instruments India**