



Email : sales@testinglabinstruments.com

Product Name :
Flakiness Index Test

Product Code :
TEST5194RFQLAB-0024



Description :

Flakiness Index Test

Technical Specification :

Flakiness Index Test

Flakiness gauge with particle size > 6.3 mm size

Flakiness Gauges characterize the particle shape of aggregates used in asphalt and concrete paving mixes or pavement base course applications. It can also determine application rates of aggregate and asphalt material for pavement seal coats.

Aggregate particles are manually tried against slots. Aggregates not passing are identified as flaky and their percent of the total sample by weight is the flakiness index.

The presence of flaky particles is undesirable and increases the possibility of pavement break-down under heavy loads.

Weight: 2.5 Kg

Features:

Laser-cut heavy-gauge stainless steel for superior accuracy and service life.

Laser-etched markings clearly label each slot.

Testing lab instruments India

